



PIANTA DELLE FONDAZIONI



plinti 1, 4, 16, 19, 31, 34, 46, 49, 61, 64, 76, 79, 91, 94, 106, 109



plinti 2, 3, 17, 18, 32, 33, 47, 48, 62, 63, 77, 78, 92, 93